




Wooden Doll High Chair

ASSEMBLY INSTRUCTIONS

Put Together
in Just 6
Simple Steps!



This doll
chair is not
intended for child
seating. Use only
for toy dolls.

Have a
question
or need help?
Give us a call!
1-800-284-3948

Item # 9382

We care about your comments. Please call us!

Melissa & Doug
1-800-284-3948
www.MelissaAndDoug.com

Melissa & Doug products meet or exceed U.S. testing standards and pass our high quality requirements.

© Melissa & Doug, LLC, P.O. Box 590, Westport, CT 06881

MADE IN CHINA

⚠ WARNING:
CHOKING HAZARD - Small Parts.
Not for children under 3 years.

⚠ CAUTION:
ADULT ASSEMBLY REQUIRED.

Ages 3+

THANK YOU!

Thank you for choosing the Melissa & Doug Wooden Doll High Chair! It's a terrific way to help nurture a child's creativity and imagination, and to inspire children to dote on their dolls for years to come.

NOW IT'S TIME TO PUT IT TOGETHER!

Don't worry, assembling your new high chair is simple, and we're here to help. Here are a few tips before you begin:

- Read through all the instructions first.
- Clear a flat, covered space (carpeted is best) to lay out all the materials so everything is close at hand.
- You will need a Phillips head screwdriver (not included) and the included Allen wrench to assemble the chair. We've included everything else you will need. All parts are labeled with a sticker (A-H; 1-3).
- The instructions include lots of helpful pictures—we show you, step-by-step, exactly how to align pieces and parts for speedy and accurate assembly. Note that hardware needed for each step is shown in the upper right corner of the page, each piece being added in a given step is highlighted in gray, and the “assembled view” (what it looks like in the finished product when the step is completed) is included in the lower right corner of every page.
- In the instructions, the name of a part is followed by a letter or number in parentheses. This letter or number corresponds to the sticker on the part, as well as the picture of the part shown on page 2.
- Helpful hints are highlighted with a large exclamation point.



IMPORTANT: Helpful hints are found here.

- If you have any questions, we're here for you! Give our customer care team a call at 1-800-284-3948!
-

WARNINGS!


Retain these instructions for future reference.

- This doll chair is not intended for child seating. Use only with toy dolls.
 - Do not allow children to sit or stand on any part of the chair.
 - Never place computers, televisions, or other heavy objects on top of the chair.
 - The chair must be assembled as instructed.
-


MAINTENANCE:

Ensure the high chair continues to function properly and safely by regularly checking the hardware and tightening when necessary.


WOOD PARTS - Be Smart—Sort Your Parts




A seat




B front legs




C right armrest




D left armrest




E spindle (2)



F seat back




G back legs



H tray


METAL COMPONENTS



1 hex head bolt (12)



2 barrel nut (6)




3 Allen wrench





IMPORTANT: Some packages of hardware may have extra pieces.

How to Correctly Install Barrel Nuts



STEP 1 - Every Journey Begins with the First Step




Using 2 hex head bolts (part 1), attach the seat (part A) to the front legs (part B). Make sure the legs are facing the correct direction, and that they attach to the underside of the seat.



STEP 2 - A Place to Rest

Install 2 barrel nuts (part 2) into the right and left armrests (parts C and D). Refer to instructions on page 3 regarding how to properly install barrel nuts.




Using 2 hex head bolts (part 1) attach the arm rests to the seat.



Assembled View

STEP 3 - Secure the Spindles




Using 2 hex head bolts (part 1), attach the 2 spindles (part E) to the front legs.



Assembled View

STEP 4 - Get Back

Install 2 barrel nuts (part 2) into the left and right armrests. Using 2 hex head bolts (part 1), attach the back (part F) to the armrests.




Assembled View



STEP 5 - Get a Leg Up

Install 2 barrel nuts (part 2) into the seat (part A). Using 4 hex head bolts (part 1), attach the back legs (part G) to the seat (part A) and the spindles (part E).

Note: The spindles already have threaded inserts.





! IMPORTANT: The slanted edge on the back legs (part G) should match the slanted edge of the seat back (part F).



Assembled View

STEP 6 - “Tray” Bien! You’ve Reached the End!

Slide the tray (part H) into the slots in the armrests as shown. The slots have bumps on the bottom to keep the tray in place, so removing or inserting the tray may require a slight lift.




Assembled View

YOU DID IT!

Now the real fun begins—it’s time to serve pretend play meals to favorite dolls in this sturdy and stylish high chair!

ACCESSORIZE

Dolls up to 20 inches tall fit in the Melissa & Doug Wooden Doll High Chair. It’s designed to play perfectly with the eight-piece Melissa & Doug Time to Eat! Feeding Set (#4888).



It includes 2 disappearing liquid bottles, 2 baby food containers, a durable plastic divided plate, fork, spoon, and an embroidered bib. To find this item and more dolls and doll accessories, visit us at MelissaAndDoug.com!